1-6. Firmware Upgrade

Use the SD memory card that stores the upgrading data to upgrade the firmware for this unit.

Note

For how to obtain the upgrading data, contact your local Sony Sales Office/Service Center.

Equipment required

- SD memory card

  Note

  - For the type of SD memory card are available for this unit, refer to the operating instructions.
  - Use the SD memory card formatted by the format function of this unit. For detail of the format function, refer to the operating instructions.

Checking Version

1. Check the current version with the Version of the System menu.

   Note

   For display and operation the System menu, refer to the operating instructions.

Preparation

1. Copy the upgrading data to the root folder of the SD memory card.

Procedure

1. Insert the SD memory card prepared in “Preparation”.
2. Press the MENU button to display the setup menu.
3. Select System, Version and Version Up with the SEL/SET dial.
4. The update confirmation screen appears and update starts.

   Note

   - There are two update progress phases to perform operations shown below.
     1) Phase 1: Stores the update file contained in the SD card in the unit.
     2) Phase 2: Starts update with the update file stored in the unit.
   - Approximate time lapse and progress rate are displayed on the LCD monitor and the viewfinder during update. The REC lamp on the right side of the unit blinks at intervals of 1 Hz (1 second). When the update is completed, the REC lamp lights.
     If an error occurs during update, the REC lamp blinks at intervals of 4 Hz (0.25 seconds).

     Note

     When information on the indication of progress or the REC indicator is being updated, approximate progress rate or blinking of the REC indicator may be interrupted.

5. When an update completion message appears, turn off and on the power of the unit.
6. Check that the version is correct with the Version of the System menu.